WARNING: DISCONNECT POWER AT THE MAIN FUSE BOX BEFORE INSTALLATION.

WARNING:

This fixture is intended for installation in accordance with the National Electrical Code (NEC) and all local code specifications. If you are not familiar with code requirements, installation by a certified electrician is recommended.

Before assembly, remove all parts and part packages from box. If anything is missing, please contact the retailer from which the product was purchased.



ITEM#: 47073/3

1. Position mounting bracket (A) so threaded ends of attached fixture mounting screws (E) are facing out. В 2. Carefully pull house wires through large hole in mounting bracket (A). 3. Align holes in mounting bracket (A) with holes in junction box. Make sure fixture mounting screws (E) are level. 4. Thread each junction box screw (B) into holes in mounting bracket (A) and into holes in junction box. Tighten junction box screws (B) to secure mounting bracket (A) to junction box. CAUTION: JUNCTION Make sure house wires are pulled completely BOX through hole in mounting bracket. DO NOT pinch wires between mounting bracket and wall. R 5. Strip 3/4" of insulation from ends of fixture wires. 6. Slightly loosen ground screw on mounting bracket (A). Do not completely remove ground screw. Wrap house ground wire (copper) around ground screw, leaving enough ground wire to attach to fixture ground wire. Twist end of FIXTURE fixture ground wire and end of house ground GROUND GROUND wire together. Twist wire nut (C) onto ends of WIRE CREW wires. Completely tighten wire nut (C). Reference HOUSE GROUND chart below for correct wire connections. WIRF (COPPER) Connect Supply (House) Ground Copper Wire to: 1/1 1/, Bare Copper Wire or, Bare Silver Wire or, 1/1 Green Insulated Wire. 1/1

ITEM#: 47073/3

Connect Black Lead Connect White Neutral 7. Twist end of house lead wire (black) and end Supply (House) Wire to: Supply (House) Wire to: of fixture lead wire together. Twist wire nut (C) Black Wire or, White Wire or, onto ends of wires. Completely tighten wire nut (C). Twist end of house neutral wire (white) and *Parallel Cord *Parallel Cord (Square and Ridged) or, (Round and Smooth) or, end of fixture neutral wire together. Twist wire nut (C) onto ends of wires. Completely tighten No printed words on Printed words on wire nut (C). Reference chart to the right for wire insulation or, wire insulation or, correct wire connections. Insulated Wire Insulated Wire 8. Wrap electrical tape (not included) around wire (other than green) (other than green) with Copper Conductor. with Silver Conductor. nuts (C) and wires. Ensure wires are securely fastened into wire nuts. *When parallel wire (SPT 1 & SPT 2) is used: 9. Carefully push all wires and wire nuts into The lead wire is round in shape or smooth. The neutral wire is square in shape or ridged. junction box. FIXTURE LEAD WIRE HOUSE LEAD WIRE (BLACK) IOUSE GROUND WIRE (COPPER) FIXTURE GROUND FIXTURE NEUTRAL WIRE HOUSE NEUTRAL WIRE (WHITE) 10. Place backplate (D) over mounting bracket (A). Pass holes in backplate (D) over ends of fixture mounting screws (E). CAUTION: Do not pinch wires between backplate and wall. 11. Screw one threaded cap (F) onto end of each fixture mounting screw (E). Tighten both threaded caps (F) to secure fixture (D) to wall. DO NOT over tighten. 12. Screw recommended bulbs (E12 candelabra bulb type, not included) into sockets. Verify correct bulb wattage marked on socket of fixture. F WARNING: DO NOT exceed maximum bulb wattage. 1/, 1/1 BULB **Instructions for Mounting Fixture Outdoors** or in Wet Location 1. Mounting surface should be clean, dry, flat and 1/4" larger than canopy on all sides. Any F gaps between mounting surface and canopy exceeding 3/16" should be corrected as 1/1 D required. 2. Apply silicone caulking compound around top and sides of canopy where back of canopy meets wall surface to prevent water from seeping into junction box. Leave bottom unsealed so moisture can drain out. **MAINTENANCE NOTE:** Only use a soft damp cloth to clean fixture as needed. DO NOT use harsh chemicals on fixture. Harsh chemicals may damage fixture. 1 Coastal conditions may cause mineral and residue build-up on fixture. It is recommended that customers in coastal areas clean all external surfaces of fixture once every two weeks with a wet cloth.